

WIRING FOR ALL ARCTIC CAT AND YAMAHA 120'S

Rev limiter BLACK
wire connects to
engine

Rev limiter BROWN wire
connects to double
YELLOW engine wire

Rev limiter BLUE wire
connects to BLACK
engine kill wire

WIRING FOR ALL POLARIS 120'S

Rev limiter BLACK
wire connects to
engine

Rev limiter BLUE
wire connects to
BLACK engine kill
wire

Rev limiter BROWN wire
connects to double
YELLOW engine wire

INSTALLATION WIRING INSTRUCTIONS

- *Install Rev Limiter using Velcro or Zip ties to a secure location.
- *Unplug headlight wire from back of headlight for proper Rev Limiter operation. Note: (ISR Legal)
- *Black wire from Rev Limiter must be grounded directly to engine.
- *Blue wire from Rev Limiter connects to Black engine kill wire. (On Polaris zip tie to hold in place)
- *Brown wire from Rev Limiter connects to Double Yellow wire on engine. (On Skidoo use Pink wire)
- * Plug Rev Limiter into battery box wire, install 9 volt battery and turn switch to ON.

Rev Limiter will limit engine to 6800 to 6900 RPMs on all sleds