2200 502501

JUNIOR ENDURO RULES

JUNIOR 14 -17 FACTORY STOCK

- 1. This class will follow all the rules for the Factory Stock based class
- Restricted throttle kit not to allow more than 50% throttle opening must be installed designated throttle kit part numbers will be supplied by brand.

JUNIOR ADVANCEMENT

WHEN AN ISR COMPETITOR REACHES THE AGE OF 14 YEARS AND QUALIFIES FOR JUNIOR COMPETITION, HE/SHE MAY BE ADVANCED UP TO THE NEXT LEVEL, BUT ONLY AFTER FULLFILLING ALL REQUIREMENTS BELOW:

AFFILIATE RESPONSIBILITIES

- Before an affiliated sanctioning body may advance Junior drivers, it must have a bona fide junior program.
- The affiliate's board/driver classification committee is responsible for verifying a Junior's driving ability.
 Junior competitors shall be
- Junior competitors shall be required to perform practice laps/runs from time to time to allow race officials to observe their progress in learning the handling skills required to advance.
- 4. Junior advancement is at the discretion of the driver's classification committee and can be reviewed at any time. The committee has the authority to advance, demote or deny advancement to any driver. The decisions of the classification committee are final.
- 5. The affiliate board/driver classification committee will not

advance drivers until all DRIVER/PARENTAL RESPONSIBILITIES have been fulfilled and all completed and signed documents are on file.

DRIVER / PARENTAL RESPONSIBILITIES

- 1. A Junior competitor must compete in at least one entire event in a class before becoming eligible for advancement.
- Before a Junior may advance to a senior class, he/she must meet the Junior advancement requirements established by the affiliates board/driver advancement committee.
- 3. He/she must petition the affiliate's board, in writing, requesting that he/she be allowed to advance.
- 4. The request for advancement must be accompanied by all new consent and release forms (as specified above).
- 5. The request must be approved in writing by the affiliate board to advance.
- Before advancing to a Pro Division class, the Junior must be at least 16 years of age.
- Parents may request for their child to stay in a lower class if they feel the driver needs more experience to develop track and driving skills.